

- 1- Turn Off the Laptop
- 2- Disconnect Cable Charge
- 3- Unplug the Battery
- 4- Hold on the Power Key for 30 to 60 seconds
- 5- Connect Cable Charge
- 6- Turn on the Laptop
- 7- After See Login screen Turn Off the Laptop
- 8- Plug the Battery
- 9- Turn on the Laptop

Other Ways :

- In Some Laptops hold **FN + F5** Key and Turn on
- In some Laptops hold **Windows + B + Power** Key For 1 Minuit
- Try Go to Bios And set Settings To Defaults
- In Don't Removable Battery Laptops Maybe available a key on the back For Reset Battery
- Turn on the Laptop which Complete Discharge that Can't Turn On again ... Now Connect Cable Charge and Hold **F8+Shift+Power** ... Maybe ...