

AutoCAD Keyboard Shortcuts

ALT+F8	VBA Run
ALT+F11	VBA Editor
CTRL+0	Clean Screen
CTRL+1	Properties Palette
CTRL+2	DesignCenter Palette
CTRL+3	Tool Palette
CTRL+4	Sheet Set Manager Palette
CTRL+5	Info Palette (removed)
CTRL+6	DBConnect Manager
CTRL+7	Markup Set Manager Palette
CTRL+8	QuickCalc
CTRL+9	Command Line
CTRL+A	Select all objects in drawing
CTRL+B	Toggles Snap (removed)
CTRL+C	Copies objects to Clipboard
CTRL+SHIFT+C	Copies objects to Clipboard with Base Point
CTRL+D	Toggles dynamic UCS
CTRL+E	Cycles through isometric planes
CTRL+F	Toggles running object snaps
CTRL+G	Toggles Grid
CTRL+H	Toggles PICKSTYLE on/off
CTRL+SHIFT+H	Toggle Hide Palettes
CTRL+I	Toggle Coords
CTRL+SHIFT+I	Toggle Infer Constraints
CTRL+J	Executes last command
CTRL+K	Hyperlink
CTRL+L	Toggles Ortho mode
CTRL+M	(No action)
CTRL+N	Creates a new drawing
CTRL+O	Opens existing drawing
CTRL+P	Plot current drawing
CTRL+SHIFT+P	Toggle QPMODE
CTRL+Q	Exit
CTRL+R	Cycles layout viewports (removed)
CTRL+S	Saves current drawing
CTRL+SHIFT+S	Saveas
CTRL+T	Toggles Tablet mode (removed)
CTRL+V	Pastes data from Clipboard
CTRL+SHIFT+V	Pastes data from Clipboard as Block
CTRL+X	Cuts objects to Clipboard
CTRL+Y	Repeats last action
CTRL+Z	Reverses last action
CTRL+[Cancels current command
CTRL+\	Cancels current command



WWW.CADDMANAGER.COM

F1	Displays Help	
F2	Text window on/off	
F3	Toggles OSNAP	
F4	Toggles TABMODE	
F5	Toggles ISOPLANE	
F6	Toggles COORDS	Temporary Override
F7	Toggles GRIDMODE	
F8	Toggles ORTHO MODE	Temporary Override
F9	Toggles SNAP MODE	Temporary Override
F10	Toggles POLAR	Temporary Override
F11	Toggles OTRACK	Temporary Override
F12	Suppress Dynamic Input	Temporary Override
SHIFT	Toggles Orthogonal Mode	Temporary Override
SHIFT+'	Toggles Object Snap Mode	Temporary Override
SHIFT+,	Object Snap Override: Center	Temporary Override
SHIFT+.	Toggles Polar Mode	Temporary Override
SHIFT+/ SHIFT+;	Toggles Dynamic UCS Mode	Temporary Override
SHIFT+;	Enables Object Snap Enforcement	Temporary Override
SHIFT+]]	Toggles Object Snap Tracking Mode	Temporary Override
SHIFT+A	Toggles Object Snapmode	Temporary Override
SHIFT+C	Object Snap Override: Center	Temporary Override
SHIFT+D	Disable All Snapping and Tracking	Temporary Override
SHIFT+E	Object Snap Override: Endpoint	Temporary Override
SHIFT+F1	Subobject Selection, No filter	
SHIFT+F2	Subobject Selection, Vertex	
SHIFT+F3	Subobject Selection, Edge	
SHIFT+F4	Subobject Selection, Face	
SHIFT+F5	Solid History	
SHIFT+L	Disable All Snapping and Tracking	Temporary Override
SHIFT+M	Object Snap Override: Midpoint	Temporary Override
SHIFT+P	Object Snap Override: Endpoint	Temporary Override
SHIFT+Q	Toggles Object Snap Tracking Mode	Temporary Override
SHIFT+S	Enables Object Snap Enforcement	Temporary Override
SHIFT+V	Object Snap Override: Midpoint	Temporary Override
SHIFT+X	Toggles Polar Mode	Temporary Override
SHIFT+Z	Toggles Dynamic UCS Mode	Temporary Override

3A	3DARRAY	D	DIMSTYLE
3DO	3DORBIT	DAL	DIMALIGNED
3DP	3DPRINT	DAN	DIMANGULAR
3DW	3DWALK	DAR	DIMARC
3F	3DFACE	JOG	DIMJOGGED
3M	3DMOVE	DBA	DIMBASELINE
3P	3DPOLY	DBC	DBCCONNECT
3R	3DROTATE	DC	ADCENTER
3S	3DSCALE	DCE	DIMCENTER
A	ARC	DCO	DIMCONTINUE
AC	BACTION	DCON	DIMCONSTRAINT
ADC	ADCENTER	DDA	DIMDISASSOCIATE
AA	AREA	DDI	DIMDIAMETER
AL	ALIGN	DED	DIMEDIT
3AL	3DALIGN	DI	DIST
AP	APPLOAD	DIV	DIVIDE
AR	ARRAY	DJL	DIMJOGLINE
-AR	-ARRAY	DJO	DIMJOGGED
ARR	ACTRECORD	DL	DATALINK
ARM	ACTUSERMESSAGE	DLI	DIMLINEAR
-ARM	-ACTUSERMESSAGE	DLU	DATALINKUPDATE
ARU	ACTUSERINPUT	DO	DONUT
ARS	ACTSTOP	DOR	DIMORDINATE
-ARS	-ACTSTOP	DOV	DIMOVERRIDE
ATI	ATTIPEDIT	DR	DRAWORDER
ATT	ATTDEF	DRA	DIMRADIUS
-ATT	-ATTDEF	DRE	DIMREASSOCIATE
ATE	ATTEDIT	DRM	DRAWINGRECOVERY
-ATE	-ATTEDIT	DS	DSETTINGS
ATTE	-ATTEDIT	DST	DIMSTYLE
		DT	TEXT
		DV	DVIEW
		DX	DATAEXTRACTION
B	BLOCK	E	ERASE
-B	-BLOCK	ED	DDEDIT
BC	BCLOSE	EL	ELLIPSE
BE	BEDIT	ER	EXTERNALREFERENCES
BH	HATCH	ESHOT	EDITSHOT
BO	BOUNDARY	EX	EXTEND
-BO	-BOUNDARY	EXIT	QUIT
BR	BREAK	EXP	EXPORT
BS	BSAVE	EXT	EXTRUDE
BVS	BVSTATE		
C	CIRCLE	F	FILLET
CAM	CAMERA	FI	FILTER
CBAR	CONSTRAINTBAR	FSHOT	FLATSHOT
CH	PROPERTIES		
-CH	CHANGE	G	GROUP
CHA	CHAMFER	-G	-GROUP
CHK	CHECKSTANDARDS	GCON	GEOCONSTRAINT
CLI	COMMANDLINE	GD	GRADIENT
COL	COLOR	GEO	GEOGRAPHICLOCATION
CO	COPY	GR	DDGRIPS
CP	COPY		
CT	CTABLESTYLE		
CUBE	NAVVCUBE		
CYL	CYLINDER		

H	HATCH	NORTH	GEOGRAPHICLOCATION
-H	-HATCH	NSHOT	NEWSHOT
HB	HATCHTOBACK	NVIEW	NEWVIEW
HE	HATCHEDIT		
HI	HIDE	O	OFFSET
		OP	OPTIONS
I	INSERT	ORBIT	3DORBIT
-I	-INSERT	OS	OSNAP
IAD	IMAGEADJUST	-OS	-OSNAP
IAT	IMAGEATTACH		
ICL	IMAGECLIP	P	PAN
IM	IMAGE	-P	-PAN
-IM	-IMAGE	PA	PASTESPEC
IMP	IMPORT	PAR	PARAMETERS
IN	INTERSECT	-PAR	-PARAMETERS
INF	INTERFERE	PARAM	BPARAMETER
IO	INSERTOBJ	PATCH	SURFPATCH
		PC	POINTCLOUD
J	JOIN	PCATTACH	POINTCLOUDATTACH
		PCINDEX	POINTCLOUDINDEX
L	LINE	PE	PEDIT
LA	LAYER	PL	PLINE
-LA	-LAYER	PO	POINT
LAS	LAYERSTATE	POFF	HIDEPALETTES
LE	QLEADER	POL	POLYGON
LEN	LENGTHEN	PON	SHOWPALETTES
LESS	MESHSMOOTHLESS	PR	PROPERTIES
LI	LIST	PROPS	PROPERTIES
LMAN	LAYERSTATE	PRE	PREVIEW
LO	-LAYOUT	PRINT	PLOT
LS	LIST	PS	PSPACE
LT	LINETYPE	PSOLID	POLYSOLID
-LT	-LINETYPE	PTW	PUBLISHTOWEB
LTYPE	LINETYPE	PU	PURGE
-LTYPE	-LINETYPE	-PU	-PURGE
LTS	LTSCALE	PYR	PYRAMID
LW	LWEIGHT		
		QC	QUICKCALC
M	MOVE	QCUI	QUICKCUI
MA	MATCHPROP	QP	QUICKPROPERTIES
MAT	MATERIALS	QVD	QVDDRAWING
ME	MEASURE	QVDC	QVDDRAWINGCLOSE
MEA	MEASUREREGION	QVL	QVLAYOUT
MI	MIRROR	QVLC	QVLAYOUTCLOSE
ML	MLINE		
MLA	MLEADERALIGN		
MLC	MLEADERCOLLECT		
MLD	MLEADER		
MLE	MLEADEREDIT		
MLS	MLEADERSTYLE		
MO	PROPERTIES		
MORE	MESHSMOOTHMORE		
MS	MSPACE		
MSM	MARKUP		
MT	MTEXT		
MV	MVIEW		

R	REDRAW	V	VIEW
RA	REDRAWALL	-V	-VIEW
RC	RENDERCROP	VGO	VIEWGO
RE	REGEN	VP	DDVPOINT
REA	REGENALL	-VP	VPOINT
REC	RECTANG	VPLAY	VIEWPLAY
REG	REGION	VS	VSCURRENT
REN	RENAME	VSM	VISUALSTYLES
-REN	-RENAME	-VSM	-VISUALSTYLES
REV	REVOLVE		
RO	ROTATE	W	WBLOCK
RP	RENDERPRESETS	-W	-WBLOCK
RPR	RPREF	WE	WEDGE
RR	RENDER	WHEEL	NAVSWHEEL
RW	RENDERWIN		
		X	EXPLODE
S	STRETCH	XA	XATTACH
SC	SCALE	XB	XBIND
SCR	SCRIPT	-XB	-XBIND
SE	DSETTINGS	XC	XCLIP
SEC	SECTION	XL	XLINE
SET	SETVAR	XR	XREF
SHA	SHADEMODE	-XR	-XREF
SL	SLICE		
SN	SNAP	Z	ZOOM
SO	SOLID	ZEBRA	ANALYSISZEBRA
SP	SPELL		
SPL	SPLINE		
SPLANE	SECTIONPLANE		
SPLAY	SEQUENCEPALY		
SPLIT	MESHSPPLIT		
SPE	SPLINEDIT		
SSM	SHEETSET		
ST	STYLE		
STA	STANDARDS		
SU	SUBTRACT		
T	MTEXT		
-T	-MTEXT		
TA	TABLET		
TB	TABLE		
TEDIT	TEXTEDIT		
TH	THICKNESS		
TI	TILEMODE		
TO	TOOLBAR		
TOL	TOLERANCE		
TOR	TORUS		
TP	TOOLPALETTES		
TR	TRIM		
TS	TABLESTYLE		
UC	UCSMAN		
UN	UNITS		
-UN	-UNITS		
UNHIDE	UNISOLATEOBJECTS		
UNI	UNION		
UNISOLATE	UNISOLATEOBJECT		

Alternate Shortcuts in AutoCAD13

AV	DSVIEWER
CP	COPY
DIMALI	DIMALIGNED
DIMANG	DIMANGULAR
DIMBASE	DIMBASELINE
DIMCONT	DIMCONTINUE
DIMDIA	DIMDIAMETER
DIMED	DIMEDIT
DIMTED	DIMTEDIT
DIMLIN	DIMLINEAR
DIMORD	DIMORDINATE
DIMRAD	DIMRADIUS
DIMSTY	DIMSTYLE
DIMOVER	DIMOVERRIDE
LEAD	LEADER
TM	TILEMODE

Aliases for Hyperlink/URL Release 14

SAVEURL	SAVE
OPENURL	OPEN
INSERTURL	INSERT

Discontinued in AutoCAD 2000

AAD	DBCCONNECT
AEX	DBCCONNECT
ALI	DBCCONNECT
ASQ	DBCCONNECT
ARO	DBCCONNECT
ASE	DBCCONNECT
DDATTDEF	ATTDEF
DDATTEXT	ATTEXT
DDCHPROP	PROPERTIES
DDCOLOR	COLOR
DDLMODES	LAYER
DDLTYPE	LINETYPE
DDMODIFY	PROPERTIES
DDOSNAP	OSNAP
DDUCS	UCS

Discontinued in AutoCAD 2004

ACADBLOCKDIALOG	BLOCK
ACADWBLOCKDIALOG	WBLOCK
ADCENTER	ADCENTER
BMAKE	BLOCK
BMOD	BLOCK
BPOLY	BOUNDARY
CONTENT	ADCENTER
DDATTE	ATTEDIT
DDIM	DIMSTYLE
DDINSERT	INSERT
DDPLOTSTAMP	PLOTSTAMP
DDRMODES	DSETTINGS
DDSTYLE	STYLE
DDUCS	UCSMAN
DDUCSP	UCSMAN
DDUNITS	UNITS
DDVIEW	VIEW
DIMHORIZONTAL	DIMLINEAR
DIMROTATED	DIMLINEAR
DIMVERTICAL	DIMLINEAR
DOUGHNUT	DONUT
DTEXT	TEXT
DWFOUT	PLOT
DXFIN	OPEN
DXFOUT	SAVEAS
PAINTER	MATCHPROP
PREFERENCES	OPTIONS
RECTANGLE	RECTANG
SHADE	SHADEMODE
VIEWPORTS	VPORTS
EDWFX	EXPORTDWF
EDWF	EXPORTDWF
EPDF	EXPORTPDF
-QPUB	EXPORT

Discontinued in AutoCAD 2007

RMAT	MATBROWSEROPEN
FOG	RENDERENVIRONMENT
FINISH	MATERIALS
SETUV	MATERIALMAP
SHOWMAT	LIST
RFILEOPT	RENDERPRESETS
RENDSCR	RENDERWIN

Discontinued in AutoCAD 2009

DASHBOARD	RIBBON
DASHBOARDCLOSE	RIBBONCLOSE